

J50

Spare parts

Ersatzteile

Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar

This diagram illustrates the exploded view of a mechanical assembly, likely a small engine or pump. The components are numbered as follows:

- 1**: Main frame or housing.
- 2**: Small pin or fastener.
- 3**: Small bracket or plate.
- 4**: Long curved arm or lever.
- 5**: Long curved arm or lever.
- 6**: Small pin or fastener.
- 7**: Small pin or fastener.
- 8**: Small pin or fastener.
- 9**: Small pin or fastener.
- 10**: Small pin or fastener.
- 11**: Small pin or fastener.
- 12**: Small pin or fastener.
- 13**: Small pin or fastener.
- 14**: Small pin or fastener.
- 15**: Small pin or fastener.
- 16**: Small pin or fastener.
- 17**: Small pin or fastener.
- 18**: Small pin or fastener.
- 19**: Small pin or fastener.
- 20**: Small pin or fastener.
- 21**: Small pin or fastener.
- 22**: Small pin or fastener.
- 23**: Small pin or fastener.
- 24**: Small pin or fastener.
- 25**: Small pin or fastener.
- 26**: Small pin or fastener.
- 27**: Small pin or fastener.
- 28**: Small pin or fastener.
- 29**: Small pin or fastener.
- 30**: Small pin or fastener.
- 31**: Small pin or fastener.
- 32**: Small pin or fastener.
- 33**: Small pin or fastener.
- 34**: Small pin or fastener.
- 35**: Small pin or fastener.
- 36**: Small pin or fastener.
- 37**: Small pin or fastener.
- 38**: Small pin or fastener.
- 39**: Small pin or fastener.
- 40**: Small pin or fastener.
- 41**: Small pin or fastener.
- 42**: Small pin or fastener.
- 43**: Small pin or fastener.
- 44**: Small pin or fastener.
- 45**: Small pin or fastener.
- 46**: Small pin or fastener.
- 47**: Small pin or fastener.
- 48**: Small pin or fastener.
- 49**: Small pin or fastener.
- 50**: Small pin or fastener.
- 51**: Small pin or fastener.
- 52**: Small pin or fastener.
- 53**: Small pin or fastener.
- 54**: Small pin or fastener.
- 55**: Small pin or fastener.
- 56**: Small pin or fastener.
- 57**: Small pin or fastener.

ROTARY LAWN MOWER - - MODEL NUMBER J50 (96111001304) PRODUCT NUMBER 961 11 00-13

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532 19 60-25	Control Bar	29	532 40 16-29	Spacer
2	532 19 47-88	Rope Guide	30	- - -	Engine, Briggs & Stratton, Model Number 9T502 (order parts from engine manufacturer)
3	532 12 50-78	Engine Washer	31	532 40 64-28	Selector Spring
4	532 19 60-24	Upper Handle	32	532 08 78-77	Selector Knob
5	532 15 34-06	Lower Handle	33	532 40 78-71	Axle Arm Assembly
6	532 13 20-04	Nut, Hex	34	532 40 16-30	Washer, Curved, Cylindrical
7	532 19 15-74	Handle Bolt 5/16-18 x 1-3/4	35	532 40 16-38	Shoulder Bolt
8	532 12 51-62	Up-Stop Bracket	36	532 40 52-68	Wheel & Tire Assembly
9	532 08 58-25	Screw	37	532 40 91-48	Nut, Hex
10	532 70 08-92	Engine Zone Control Cable	38	532 15 04-06	Hex Head Thread Rolling Screw 3/8-16 x 1-1/8
11	532 75 06-34	Nut, Hex	39	532 41 66-95	Kit, Lawn Mower Housing
12	532 06 64-26	Wire Tie	40	532 85 10-84	Hex Head Screw 3/8-24 x 1-3/8 Grade 8
13	532 05 17-93	Hairpin Cotter	41	532 14 97-41	Thread Cutting Screw 5/16-18 x 3/4
14	532 19 19-38	Wing Nut, Steel	42	532 18 21-66	Danger Decal
15	532 41 35-68	Discharge Guard	43	873 93 05-00	Locknut, Hex 5/16-18
16	532 85 02-63	Helical Lockwasher 3/8	44	532 19 79-91	Clip, Cable
17	532 06 91-80	Nut, Hex	45	532 08 38-16	Screw #10
18	532 85 10-74	Hardened Washer	46	532 11 11-90	Clamp, Cable
19	532 41 18-32	Torsion Spring	47	532 70 04-17	Control Throttle
20	532 14 51-06	Blade, 20"	48	532 18 33-65	Screw 1/4-20 x 2.12
21	532 08 86-02	Bracket, Mounting	55	532 14 15-19	Front Baffle
22	532 15 02-15	Hinge Rod	56	873 80 04-00	Nut, Hex
23	532 15 41-47	Footguard	57	532 41 24-00	Mulcher Plug
24	532 41 08-07	Wheel Adjusting Bracket	- -	532 14 15-20	Rear Baffle (not shown)
25	532 85 09-77	Blade Adapter	- -	532 40 00-56	Operator's Manual, European
26	532 17 09-75	Handle Bracket Assembly, RH	- -	532 40 00-55	Operator's Manual, Scandinavian
27	532 17 09-77	Handle Bracket Assembly, LH	- -	532 40 00-57	Operator's Manual, East Bloc
28	532 06 15-37	Washer	- -	532 40 00-58	Operator's Manual, Baltic

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm. **IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.