


HUSQVARNA - КАТАЛОГ ЗАПЧАСТЕЙ

: HUSQVARNA LC 247S

Список запчастей


СПИСОК ЗАПЧАСТЕЙ

A LC247S Deck



PXM_REF	PXM_PARTNO	ОПИСАНИЕ	PXM_REMARK	КОЛ-ВО
1	587151003	Крышка в сборе		1
2	584805301	Наклейка		2
3	587212102	HANDLE SUPPORT		1
4	587212302	HANDLE SUPPORT		1
5	578175802	SCREW ITXPANT		7
6	587674401	Пружина		1
7	587095402	КРЫШКА		1
8	579317401	STRAP		1
9	587101403	HATCH		1
10	586984601	AXLE		1
11	587101501	Пружина		1
12	587203701	COVER HALF		1
13	587203801	COVER HALF		1
14	587697401	KNOB		1
15	589597601	Пружина		1
16	502435301	SCREW ITXPANT		11
17	587160801	ROD		1
18	587687001	Тяга		2
19	735311220	E-CLIP		2
20	587072501	LINK ARM		2
21	587072401	LINK ARM		1
22	501861001	BUSHING		2
23	579682802	TUBE		2
24	544342301	PINION		2
25	735311401	Шайба		2
26	587204002	Защита от пыли		2
27	587072601	WHEEL AXLE		1
28	587072602	WHEEL AXLE		1
29	577092801	Шайба		1
30	587990901	Гайка		4
31	584142203	WHEEL	For 967345301 - 2016-01	1
31	582305701	WHEEL	For 967345301 - 2016-11	2
32	587631501	WHEEL		2
33	584159301	CAP		2
34	587632701	CAP		2
35	584159401	NUT PROTECTION		4
36	587199901	BELT COVER	For 967345301 - 2016-01	1
36	587199902	BELT COVER	For 967345301 - 2016-11	1
37	588202701	SKID PLATE		1
38	589214801	MULCH KIT		1
39	587702701	MULCH PLUG		1
40	588275701	MOWER BLADE		1
41	589018701	THREAD INSERT		1

B LC247S
HANDLE



PXM_REF	PXM_PARTNO	ОПИСАНИЕ	PXM_REMARK	КОЛ-ВО
1	582818102	Передняя ручка 371K		1
2	501110101	TUBE		1
3	587101702	BAIL		1
4	587101802	BAIL		1
5	587102502	GRIP		1
6	503320901	BUSHING		4
7	531208043	Кронштейн		1
8	535475245	SCREW ENHFM		1
9	732251601	HEXAGON LOCKING NUT		1
10	587102701	REPL BY 5022615-01		1
11	725236861	SCREW ENHFT		1
12	579134601	Проставка		2
13	582105301	Тросик	For 967345301	1
13	588204808	Провод	For 970541201	1
14	582105201	Тросик		1
15	587780401	Шайба		2
16	588157302	BOLT O 16X32		2
17	588157401	Шайба		2
18	731431801	HEXAGON THIN NUT		2
19	587237201	KNOB		2
20	506570104	SCREW ENHFM		2
21	732211801	LOCK NUT		2
22	734182051	Шайба		2


C LC247S Engine

For 967345301, 2016-11
For 970541201, 2022

 **Husqvarna**


LC 247S

Husqvarna engine HS 139A




PXM_REF	PXM_PARTNO	ОПИСАНИЕ	PXM_REMARK	КОЛ-ВО
1	588638801	Продукция	For 967345301	1
1	531450701	Продукция	For 970541201 - HS 139A	1
2	588878701	SHROUD	For 967345301	1
3	588888502	Наклейка	For 967345301	1
4	578295101	Втулка		3
5	578294801	SCREW ЕННFT		3
6	588645701	BLADE SUPPORT		1
7	503259401	Шайба		1
8	588275510	Нож для обрез.веток 80 см		1
9	503332501	Пружина		1
10	504456403	SCREW ЕННН		1
11	582370301	TRANSMISSION FT5		1
12	735311401	Шайба		4
13	501869702	PINION		1
14	501869701	PINION		1
15	589324604	Ремень приводной 272К 14"	For 967345301	1
15	579819304	Ремень приводной 272К 14"	For 970541201	1
16	582041101	Гачка 250PS		2
17	504460801	Шайба		2
18	582362001	Пружина		1
19	531240804	Наклейка	For 970541201	1

C LC247S
Engine
For 967345301, 2016-01



PXM_REF	PXM_PARTNO	ОПИСАНИЕ	PXM_REMARK	КОЛ-ВО
1	588638801	Продукция		1
2	588878701	SHROUD		1
3	588888502	Наклейка		1
4	578295101	Втулка		3
5	578294801	SCREW ENHFT		3
6	588645701	BLADE SUPPORT		1
7	503259401	Шайба		1
8	588275510	Нож для обрез.веток 80 см		1
9	503332501	Пружина		1
10	504456403	SCREW ENHИ		1
11	587182101	GEARBOX		1
12	544342301	PINION		2
13	735311401	Шайба		2
14	587938601	BELT GUIDE		1
15	587938501	BELT GUIDE		1
16	589563301	Ремень приводной 272К 14"		1

D



PXM_REF	PXM_PARTNO	ОПИСАНИЕ	PXM_REMARK	КОЛ-ВО
1	587292301	GRASSBAG		1
2	587182001	Рама		1
3	588188502	Передняя ручка 371K		1
4	588188402	Передняя ручка 371K		1
5	502435301	SCREW ITXPANT		1