




235R

235FR


Spare parts
Ersatzteile
Pièces détachées
Reserve onderdelen
Repuestos
Reservdelar

A 235FR, 235R


*compl 544 21 64-01



B 235FR, 235R




C 235FR, 235R



D 235FR, 235R

*compl 537 18 35-07




compl 544 25 10-01


503 21 66-18
544 25 14-01
544 25 08-01







G 235FR, 235R




H




J***compl 503 90 47-02****K*****compl 502 18 95-02****L*****compl 503 84 00-02****M**


N ***compl 503 79 06-01**




P ***compl 537 10 41-01 (R,FR ø40)**




Q ***compl 502 21 28-04**










- ① 530 03 51-73
Set of gaskets
Dichtungssatz
Jeu de joints
Juego de juntas
Packningssats

S Duo Balance
 compl 537 27 57-01
 compl 537 27 57-03 US








T Accessories Zubehör Accessoires Acessorios Tillbehör

*compl 502 21 60-14




Oil Airfilter
Öl Luftfilter
Aceite Filtro Air
Huile Filtre air
Olja Luftfilter



U 235FR, 235R

*compl 537 38 77-01



U 235FR, 235R

*compl 537 33 16-01

