



535 RX

535 RXT

535 RJ

535 LS

Spare parts

Ersatzteile


Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar


A 535 RX, 535 RJ, 535 RXT, 535 LS
BEVEL GEAR



Page A 535 RX, 535 RJ, 535 RXT, 535 LS **BEVEL GEAR**


Position	Article	Quantity	Notes	Kit
1	537 18 95-01	1		20
2	503 20 02-10	1		20
3	544 08 76-01	1		20
4	537 14 74-01	1		16
5	503 20 15-01	1		16
6	537 29 59-02	1		16
7	738 21 99-00	1		16
8	503 20 03-25	2		
9	738 21 01-10	1		16
10	738 21 01-12	1		16
11	735 31 28-10	1		16
12	735 31 14-00	1		16
13	505 13 33-01	1	535 RX, 535 RXT	16
13	505 13 34-01	1	535 RJ, 535 LS	16
14	503 25 28-01	1		16
15	735 31 31-10	1		16
16	544 21 64-01	1	535 RX, 535 RXT	
16	537 29 58-02	1	535 RJ, 535 LS	
17	537 35 14-02	1	(1")	
18	537 34 35-01	1		
19	502 29 11-01	1		
20	574 30 68-01	1		

B1 535 RX, 535 RXT SHAFT




Position	Article	Quantity	Notes	Kit
1	537 21 42-01	1	535 RX, 535 RXT	
2	537 36 02-02	1		1
3	537 21 41-01	1	Ø = 28mm, L = 1483mm	1
4	537 36 02-01	1		1
5	537 31 39-01	1	Ø = 9mm, L = 1400mm	1
6	537 35 52-01	1	Ø = 8mm, L = 1527mm	
7	505 13 71-01	1		
8	505 13 72-01	1		
9	505 16 09-01	1	535 RXT	
9	537 34 98-01	1	535 RX	
10	537 13 04-02	1		
11	537 35 01-01	1		9
12	725 23 39-51	1	535 RXT	
12	725 23 31-51	1	535 RX	
13	537 37 61-01	1	535 RX	
14	503 21 75-16	1		
15	537 29 48-01	1		
16	503 20 07-78	2		
17	537 38 72-01	2		


B2 535 RJ, 535 LS SHAFT



Position	Article	Quantity	Notes	Kit
1	544 10 18-01	1	535 RJ, 535 LS	
2	537 18 26-10	1	Ø = 24mm, L = 330mm	
3	537 33 44-02	1		
4	544 25 40-01	1		
5	537 36 02-01	1		
6	537 21 41-02	1	Ø = 28mm, L = 1152mm	
7	537 31 39-02	1	Ø = 9mm, L = 1115mm	
8	537 35 52-01	1	Ø = 8mm, L = 1527mm	
9	537 29 48-01	1		




Position	Article	Quantity	Notes	Kit
1	725 23 82-85	1		
2	503 87 90-01	1		
3	537 37 63-01	1		
4	537 40 26-03	1		
5	502 28 61-01	1		
6	503 20 03-20	2		





Position	Article	Quantity	Notes	Kit
1	725 23 82-85	1		
2	502 20 38-01	1		
3	537 37 63-01	1		
4	502 19 71-01	1		
5	537 34 86-01	1		
6	505 22 04-01	1		
7	501 38 03-01	1		
8	503 20 07-78	4		
9	537 34 89-01	1		
10	537 34 87-01	1		
11	503 21 06-19	4		
12	502 28 61-01	1		
13	731 23 14-01	2		

D1 535 RX, 535 RXT THROTTLE CONTROLS



Position	Article	Quantity	Notes	Kit
1	537 17 28-01	1		
2	731 23 14-01	1		
3	503 20 02-45	1		
4	537 17 29-01	1		
5	537 36 00-01	1		
6	503 75 00-02	1		
7	537 42 45-13	1		
8	503 21 66-18	2		7
9	537 16 03-02	1	535 RXT	7
9	537 16 03-01	1	535 RX	7
10	537 16 07-01	1		7
11	537 17 42-01	1		7
12	506 49 77-01	1		7
13	537 16 02-09	1	535 RXT	7
13	537 16 02-02	1	535 RX	7
14	503 22 10-13	1		7
15	537 17 43-01	1		7
16	537 41 90-01	1		7
17	503 20 07-35	1		7
18	537 35 96-02	1		
19	503 21 66-18	1		18
20	503 87 85-07	1		18
21	537 37 78-01	1		18


D2 535 RJ, 535 LS THROTTLE CONTROLS



THROTTLE CONTROLS

Position	Article	Quantity	Notes	Kit
1	503 91 81-01	1		15
2	544 10 08-01	1		15
3	503 87 80-01	1		15
4	503 87 79-03	1		15
5	503 96 14-01	1		15
6	537 41 90-01	1		15
7	503 21 66-18	5		15
8	544 23 84-01	1	Hard grip	15
8	544 10 02-02	1	Soft grip	15
9	544 23 85-01	1	Hard grip	15
9	544 10 03-02	1	Soft grip	15
10	544 10 17-02	1		15
11	731 23 14-01	1		15
12	544 11 21-01	1		15
13	503 20 03-20	1		15
14	544 10 17-02	1		15
15	544 14 36-02	1		
16	503 87 85-06	1		15, 18
17	544 17 17-02	1		15, 18
18	544 14 49-01	1		15
19	725 23 80-51	1		
20	503 87 90-01	1		
21	503 23 00-61	1		
22	544 10 10-04	1		
23	502 19 71-01	1		
24	544 10 11-01	1		
25	503 99 78-01	1	Spare part incl. Screws Pos. 26	
26	574 18 15-01	3	Captive screws	25


E 535 RX, 535 RJ, 535 RXT, 535 LS
FUEL TANK



Page E 535 RX, 535 RJ, 535 RXT, 535 LS **FUEL TANK**


Position	Article	Quantity	Notes	Kit
1	503 93 66-01	1		
2	537 04 24-12	1		
3	537 05 23-01	1		
4	537 04 24-12	1		
5	503 73 58-01	2		
6	537 18 49-01	1		
7	503 44 32-01	1		
8	544 32 88-01	1		
9	503 91 10-01	4		
10	503 91 18-02	1		

F 535 RX, 535 RJ, 535 RXT, 535 LS
CLUTCH



Page F 535 RX, 535 RJ, 535 RXT, 535 LS **CLUTCH**


Position	Article	Quantity	Notes	Kit
1	544 11 97-01	1	535 RJ, 535 LS	
1	537 32 61-01	1	535 RX, 535 RXT	
2	503 96 13-01	2		
3	740 42 06-00	2		
4	537 31 00-01	1		
5	537 32 27-01	1		
6	725 53 33-55	1		
7	503 20 03-20	3		
8	537 31 01-01	1	535 RJ, 535 LS	
8	537 31 01-02	1	535 RX, 535 RXT	
9	735 31 14-00	1		
10	503 24 07-02	2		13
11	738 21 01-04	1		13
12	735 31 28-10	1		13
13	537 30 29-01	1		
14	537 35 29-01	1		
15	503 20 03-20	3		
16	537 41 81-01	2		
17	537 41 57-01	1		
18	537 42 72-01	1		19
19	537 34 04-01	1		
20	537 04 68-01	1		

G**535 RX, 535 RJ, 535 RXT, 535 LS
CYLINDER COVER****12 — 535 RXT****13 — 535 RX****14 — 535 RJ****15 — 535 LS**

Page G 535 RX, 535 RJ, 535 RXT, 535 LS **CYLINDER COVER**


Position	Article	Quantity	Notes	Kit
1	544 16 01-02	1	Spare part incl. Screws Pos. 2	
2	573 99 43-04	1	Captive screws	1
3	503 21 29-10	4		1
4	537 42 51-02	1	Spare part incl. Screws Pos. 5	
5	574 47 70-03	1	Captive screws	4
8	503 21 75-16	2		
9	537 35 72-01	1		
10	503 21 75-16	1		
11	544 02 98-01	1		
12	576 99 86-10	1	535 RXT	
13	576 99 86-11	1	535 RX	
14	576 99 86-12	1	535 RJ	
15	576 99 86-13	1	535 LS	
16	503 21 35-12	2	535 RJ, 535 LS	
17	502 43 39-01	1	535 RJ, 535 LS	

H 535 RX, 535 RJ, 535 RXT, 535 LS
MUFFLER



Page H 535 RX, 535 RJ, 535 RXT, 535 LS **MUFFLER**


Position	Article	Quantity	Notes	Kit
1	537 32 47-01	1		3
2	724 12 87-59	1		3
3	544 11 67-01	1	Cat	
3	544 11 67-02	1	Non Cat	
4	537 33 31-01	1		
5	537 34 08-01	1		
6	503 20 03-20	1		
7	503 20 29-63	2		

J**535 RX, 535 RJ, 535 RXT, 535 LS
CARBURETOR & AIR FILTER**

Page J 535 RX, 535 RJ, 535 RXT, 535 LS **CARBURETOR & AIR FILTER**

Position	Article	Quantity	Notes	Kit
1	537 37 12-01	1		
2	537 37 11-01	1		1
3	544 01 91-01	1		1
4	537 33 43-01	1		
5	537 37 38-03	2		1
6	503 20 03-16	2		
7	503 49 71-01	1		
8	544 32 56-01	1	(ZAMA C1Q-EL36)	
9	503 23 10-06	1		
10	503 20 03-20	1		
11	544 02 58-01	1		16
12	537 33 71-01	1		16
13	503 21 29-06	1		16
14	537 35 58-01	1		16
15	544 37 27-01	1		
16	537 31 41-01	1		
17	503 21 75-50	2		
18	537 33 72-01	1		
19	537 31 42-01	1		
20	537 31 44-01	1		
21	537 38 72-01	2		
22	544 01 47-01	1		16
23	544 01 46-01	1		16
24	503 21 29-06	1		16
25	537 34 90-01	1		
26	537 34 13-01	1		


K 535 RX, 535 RJ, 535 RXT, 535 LS
STARTER



Page K 535 RX, 535 RJ, 535 RXT, 535 LS STARTER


Position	Article	Quantity	Notes	Kit
1	577 22 36-01	1		
2	503 21 79-20	1		11
3	535 07 23-01	1		11
4	537 32 50-02	1		11
5	503 85 99-01	1		11
7	505 30 51-25	1		11
8	503 54 39-01	1		11
9	544 10 25-02	1	Spare part incl. Screws Pos. 10	11
10	573 99 43-05	3	Captive screws	9, 11
11	537 21 47-07	1		
12	503 87 33-05	1		
13	735 31 08-20	2		12
14	503 87 36-01	1		12
15	503 87 35-02	2		12

L 535 RX, 535 RJ, 535 RXT, 535 LS
IGNITION



Position	Article	Quantity	Notes	Kit
1	503 21 66-18	2		
2	544 12 70-01	1		
3	503 23 51-09	1	CH RCJ6Y (Ø=14 mm)	
4	537 24 96-01	1		
5	731 71 16-51	1		


M 535 RX, 535 RJ, 535 RXT, 535 LS
CYLINDER PISTON



Page M 535 RX, 535 RJ, 535 RXT, 535 LS **CYLINDER & PISTON**

Position	Article	Quantity	Notes	Kit
1	503 20 08-23	4		8
2	503 28 90-54	2		6,8
3	503 28 91-19	1		6,8
4	503 41 41-01	1		6,8
5	737 44 10-00	2		6,8
6	537 31 28-02	1		8
7	537 33 30-01	1		
8	544 40 06-01	1	Ø = 38mm. 574 36 43-01	

N 535 RX, 535 RJ, 535 RXT, 535 LS
CRANK SHAFT




Page N 535 RX, 535 RJ, 535 RXT, 535 LS **CRANK SHAFT**

Position	Article	Quantity	Notes	Kit
1	503 26 02-02	1		8
2	738 21 01-10	1		8
3	537 29 76-01	1		8
4	503 41 41-01	1		8
5	537 29 76-01	1		8
6	738 21 01-10	1		8
7	503 26 02-02	1		8
8	544 03 90-01	1		

P

535 RX, 535 RJ, 535 RXT, 535 LS
CRANKCASE




Page P 535 RX, 535 RJ, 535 RXT, 535 LS **CRANKCASE**

Position	Article	Quantity	Notes	Kit
1	503 20 02-30	4		9
2	503 26 02-02	1		9
3	738 21 01-10	1		9
4	501 27 08-01	2		9
5	537 33 29-01	1		9
6	537 32 42-01	1		9
7	738 21 01-10	1		9
8	503 26 02-02	1		9
9	544 03 89-01	1		

Q

535 RX, 535 RJ, 535 RXT, 535 LS
CARBURETOR




Zama C1Q-EL36



Page Q 535 RX, 535 RJ, 535 RXT, 535 LS **CARBURETOR**

Position	Article	Quantity	Notes	Kit
1	544 32 56-01	1		
2	503 47 92-01	1		1
3	537 41 72-01	1		1
4	544 37 24-01	1		1
5	503 48 05-01	2		1
6	503 97 43-01	1		1
7	537 04 89-01	1		1, 43
8	537 02 04-01	1		1, 43
9	503 53 56-01	1		1
10	537 38 73-01	1		1
11	503 48 01-01	1		1
12	503 48 00-01	1		1
13	503 66 59-01	1		1
14	503 47 97-01	1		1
15	537 02 03-01	1		1
16	544 37 22-01	1		1
17	537 02 11-01	1		1
18	503 48 18-01	1		1
19	544 37 26-01	1		1
20	544 37 25-01	1		1
21	544 42 70-01	1		1
23	537 01 26-01	1		1
24	537 01 25-01	1		1
25	503 48 13-01	1		1
26	544 37 23-01	1		1
27	503 47 90-01	1		1
28	537 41 69-01	1	L	1
29	537 41 70-01	2		1
30	537 38 75-01	1	H	1
31	537 38 52-01	1		1
32	537 41 77-01	1		1
33	537 41 73-01	1		1
34	537 41 78-01	1		1
35	537 41 74-01	1		1
36	503 47 90-01	1		1
37	537 02 00-01	1		1, 43
38	537 02 01-01	1		1, 43
39	537 41 68-01	1		1
40	537 02 07-01	1		1
41	503 48 11-01	1		1
42	503 47 96-01	1		1
43	531 00 45-52	1		
44	537 38 74-01	1		1

R1 535 RX, 535 RJ, 535 RXT, 535 LS ACCESSORIES




Page R1 535 RX, 535 RJ, 535 RXT, 535 LS **ACCESSORIES**

Position	Article	Quantity	Notes	Kit
1	501 32 04-02	1	Incl. Pos. 2-7	
2	574 53 06-01	1	Spare part incl. Screws Pos. 3	1
3	573 99 43-04	2	Captive Screw M5	1, 2
4	501 32 08-01	1		1
5	574 53 26-01	1	Incl. Pos. 6-7	1
6	503 20 02-16	4		1, 5
7	574 03 95-01	4		1, 5
8	503 21 07-16	1	535 RX, 535 RXT	13
8	503 21 68-25	1	535 LS, 535 RJ	13
9	503 79 88-01	1		13
10	544 12 45-01	1	535 LS, 535 RJ	13
11	537 38 72-01	4		13
12	537 39 63-01	1	535 RX, 535 RXT	13
12	537 39 63-03	1	535 LS, 535 RJ	
13	537 33 16-01	1	535 RX, 535 RXT	
13	537 33 16-03	1	535 LS, 535 RJ	
14	503 21 68-25	1		17
15	503 79 88-01	1		17
16	544 12 45-01	1		17
17	537 34 94-03	1	535 LS, 535 RJ	
18	503 21 68-25	1		20
19	503 79 88-01	1		20
20	502 44 81-01	1		

R2

535 RX, 535 RJ, 535 RXT, 535 LS
ACCESSORIES





Page R2 535 RX, 535 RJ, 535 RXT, 535 LS ACCESSORIES


Position	Article	Quantity	Notes	Kit
1	501 19 22-01	1		
2	531 00 92-48	1	Oil Airfilter	
3	503 97 64-01	1		
4	502 28 59-01	1		
5	503 80 17-01	1		
6	537 36 21-01	1		
7	544 35 91-01	1		
8	537 31 29-01	1	200-275 mm	
9	503 89 01-02	1		
10	537 21 62-01	1		
10	537 21 62-02	1	USA	

S DUO BALANCE 35
HARNESS

1



5




Page S DUO BALANCE 35 HARNESS

Position	Article	Quantity	Notes	Kit
1	537 27 57-02	1		
1	537 27 57-04	1	US	
2	537 28 83-01	1		1
3	537 28 84-01	1		1
4	537 27 59-01	1		1
5	502 02 28-01	1		1
6	502 02 29-02	1		1,5
7	502 02 30-02	1		1,5
8	502 02 38-01	1		1,5
9	735 31 09-20	1		1,5
10	503 99 61-01	3		1
11	537 11 35-01	1		1
12	503 99 61-03	1		1

T

535 RX, 535 RJ, 535 RXT, 535 LS
SHORT BLOCK

1



Position	Article	Quantity	Notes	Kit
1	576 79 68-01	1	Assembled	