



FIG. 1: 1E36F-2A GASOLINE ENGINE



| NO. | Part No.       | Part Name           | Qty. | NO. | Part No.     | Part Name         | Qty. | NO. | Part No.       | Part Name             | Qty. |
|-----|----------------|---------------------|------|-----|--------------|-------------------|------|-----|----------------|-----------------------|------|
| 1   | GB/T67         | Screw M5 × 12       | 1    | 31  | 1E36F-3      | Washer B          | 1    | 61  | 1E36F-2A-2     | Admitting Pipe        | 1    |
| 2   | 1E40F-5.11-2   | Washer              | 1    | 32  | 1E40F-5.6-1  | Spring            | 1    | 62  | 1E36F-2A-1     | Gasket                | 1    |
| 3   | 1E40F-5.11-1   | Start Rope Reel     | 1    | 33  | 1E40F-5.6.1  | Expander          | 2    | 63  | 1E36F-2A.1     | Carburetor            | 1    |
| 4   |                | Rope                | 1    | 34  | 1E40F-5-11   | Washer            | 2    | 64  | 1E34F.1-2      | Choker Handle         | 1    |
| 5   | 1E40FP-3Z.4-7  | Recoil Spring       | 1    | 35  | 1E40F-5-12   | Screw Pin         | 2    | 65  | 1E34F.1-7      | Stop Ring             | 1    |
| 6   | 1E40F-5.11.1   | Start Cover Ass'y   | 1    | 36  | 1E36F-2-8    | Fan Cover         | 1    | 66  | GB/T6172       | Nut 4                 | 1    |
| 7   | 1E40FP-3Z.4-2  | Start Handle        | 1    | 37  | 1E36F-2.4.1  | Bearing           | 1    | 67  | 1E34F.1.1      | Clear Inside Cover    | 1    |
| 8   | 1E40FP-3Z.4-10 | Ring                | 1    | 38  | 1E36F.10-2   | Ring              | 2    | 68  | GB/T9074.4     | Screw M5 × 50         | 2    |
| 9   | GB/T9074.4     | Screw M5 × 20       | 6    | 39  | 1E36F-2.4.2  | Piston            | 1    | 69  | 1E40F-5.11     | Starter               | 1    |
| 10  | 1E40F-5-10     | Gasket              | 1    | 40  | 1E36F.10-1   | Piston Pin        | 1    | 70  | 1E34F.1-3      | Choker                | 1    |
| 11  | GB/T6170       | Nut M8              | 1    | 41  | 1E36F-2.6-3  | Gasket            | 1    | 71  | GB/T845        | Screw St4.2 × 12      | 1    |
| 12  | 1E46FP.4-2     | Start Claw          | 1    | 42  | 1E36F.10-3   | Piston Ring       | 2    | 72  | 1E34F.1-1      | Filter                | 1    |
| 13  | 1E36F.1.2-2    | Start Spring        | 1    | 43  | 1E36F-2-6    | Gasket            | 1    | 73  | 1E34FA.1-1     | Cleaner Outside Cover | 1    |
| 14  | 1E40F-5.7-1    | Start Reel          | 1    | 44  | 1E36F-2-4    | Cylinder          | 1    | 74  | 1E40F-3A.3-5   | Label                 | 1    |
| 15  | GB/T896        | Stop Ring 4         | 1    | 45  | GB/T70.1     | Screw M5 × 16     | 4    | 75  | 1E34F.1.2      | Screw                 | 1    |
| 16  | 1E36F.2        | Oil-seal            | 2    | 46  | 1E36F-2.5    | Guide Cover Ass'y | 1    | 76  | GB/T9074.4     | Screw M5 × 16         | 2    |
| 17  | 1E36F-2.6-2    | Crank Case          | 1    | 47  | L6 (LD)      | Spark Plug        | 1    | 77  | 1E34F.9.2-3    | Cleaner Cover         | 1    |
| 18  | GB/T276        | Bearing 6201/P5     | 2    | 48  | 1E40F-3A.8-2 | Spring            | 1    | 78  | 1E36F-2A.3.1-2 | Outlet Fuel Pipe      | 1    |
| 19  | 1E36F-2.4.3    | Crank Shaft         | 1    | 49  | 1E34F.5-3    | Plug Cover        | 1    | 79  | 1E36FF.8.1-1   | Plug                  | 1    |
| 20  | GB/T1099       | Key 3 × 5 × 13      | 1    | 50  | 1E34F.5-2    | Plug Cap          | 1    | 80  | 1E36F-2A.3.1-1 | Inlet Fuel Pipe       | 1    |
| 21  | GB/T119        | Pin B4 × 10         | 4    | 51  | 1E40F-5.3-1  | Plug              | 1    | 81  | 1E36F-2A.3-1   | Fuel Tank             | 1    |
| 22  | 1E40F-5A-3     | Rubber Washer       | 2    | 52  | 1E36F-2-7    | Upper Cover       | 1    | 82  | EB-415.4.1-1   | Fuel Tank Lid         | 1    |
| 23  | 1E36F-2.6-1    | Crank Case          | 1    | 53  | GB/T9074.4   | Screw M5 × 20     | 1    | 83  | EB-415.4.1.1-1 | Inlet                 | 1    |
| 24  | 1E36F-2-11     | Flash Pan           | 1    | 54  | 1E36F-2-5    | Gasket            | 1    | 84  | EB415.4.1.1-3  | Stand                 | 1    |
| 25  | GB/T9074.4     | Screw M5 × 30       | 4    | 55  | 1E36F-2.2    | Muffler           | 1    | 85  | BB415.4.1.1-2  | Gasket                | 1    |
| 26  | 1E36F          | Magneto Roto Comp.  | 1    | 56  | GB/T9074.4   | Screw M5 × 12     | 3    | 86  | BB415.4.1      | Lid Ass'y             | 1    |
| 27  | GB/T6177.1     | Nut M8              | 1    | 57  | 1E36F-2-9    | Bolt              | 2    | 87  | 1E40F-5A-4     | Stand                 | 1    |
| 28  | 1E36FA         | Ignition Coll Comp. | 1    | 58  | GB/T6177.1   | Nut M5            | 2    | 88  | 1E40F-5A-2     | Rubber Cover          | 1    |
| 29  | 1E36F-2.3.1    | Cord Comp.          | 1    | 59  | 1E36F-2.7    | Muffler Cover     | 1    | 89  | 860259         | ENGINE GASKETKIT      |      |
| 30  | GB/T9074.13    | Bolt M5 × 20        | 6    | 60  | 1E36F-2-2    | Gasket            | 1    |     |                |                       |      |

# CG330B BRUSH CUTTER



| NO | PART NO.     | PART NAME           | QTY | NO | PART NO.      | PART NAME           | QTY | NO | PART NO.        | PART NAME         | QTY |
|----|--------------|---------------------|-----|----|---------------|---------------------|-----|----|-----------------|-------------------|-----|
| 1  | CG415.3      | Gear Case Assy      | 1   | 31 | CG260.3.1     | Harness Clamp       | 1   | 61 | BL750.3-7       | Spring            | 1   |
| 2  | GB/T893.2    | Stop Ring 26        | 1   | 32 | CG260.3-1     | Clamp               | 1   | 62 | BL750.3-8       | Clock Pin         | 1   |
| 3  | GB/T894.1    | Stop Ring 10        | 1   | 33 | GB/T70.1      | Screw M5×20         | 1   | 63 | BL750.3-4       | Handgrip          | 1   |
| 4  | GB/T276      | Bearing 6000-2RS/P5 | 2   | 34 | GB/T889.1     | Nut M5              | 2   | 64 | BL750.3-1       | Spring            | 1   |
| 5  | CG415D.6-4   | Pinion              | 1   | 35 | CG415.2       | Clutch Comp.        | 1   | 65 | BL750.3-5       | Box, Right        | 1   |
| 6  | CG415.3-1    | Steel Plate Cap     | 1   | 36 | CG415D.1.1    | Clutch Drum Comp.   | 1   | 66 | GB/T845         | Screw ST2.9×18    | 2   |
| 7  | GB/T70.1     | Screw M6×20         | 5   | 37 | GB/T893.1     | Stop Ring 35        | 1   | 67 | GB/T70.1        | Screw M5×30       | 1   |
| 8  | GB/T93       | Washer 6            | 5   | 38 | GB/T276       | Bearing 6202-2RS/P5 | 1   | 68 | CG260B-CE.1.1.1 | Cable Comp.       | 1   |
| 9  | GB/T9074.4   | Screw M5×12         | 4   | 39 | GB/T894.1     | Stop Ring 15        | 1   | 69 | BG-328A-2       | Tube              | 1   |
| 10 | GB/T29.2     | Bolt M6×12          | 1   | 40 | CG305F.14-1   | Linker              | 1   | 70 | CG328.2.1.1     | Stop Button Comp  | 1   |
| 11 | GB/T97.1     | Washer 6            | 5   | 41 | CG305F.14-2   | Rubber Cover        | 1   | 71 | BL750.3-3       | Handgrip          | 1   |
| 12 | BG305.12.4-4 | Gear Case           | 1   | 42 | GB/T70.1      | Screw M5×25         | 2   | 72 | BL750.3-2       | Spring            | 1   |
| 13 | BG305.12.4-9 | Blade Cover         | 1   | 43 | GB/T93        | Washer 5            | 2   | 73 | BL750.3-6       | Box, Left         | 1   |
| 14 | GB/T276      | Bearing 6000/P5     | 1   | 44 | GB/T97.1      | Washer 5            | 2   | 74 | CG305F.8        | Nylon Cutter Head | 1   |
| 15 | BG-328.9.5-2 | Gear                | 1   | 45 | CG305F.14-3   | Clamp B             | 1   | 75 | CG305F.8.1      | Case              | 1   |
| 16 | CG305F.1-1   | Gear Shaft          | 1   | 46 | CG305F.14-4   | Clamp A             | 1   | 76 | CG305F.8.4      | Left Nut          | 1   |
| 17 | GB/T276      | Bearing 6002-2RS/P5 | 1   | 47 | BG415-1       | Wire Clamp Band     | 1   | 77 | CG305F.8.5      | Washer            | 1   |
| 18 | GB/T893.2    | Stop Ring 32        | 1   | 48 | CG305F.3A     | Harness Assy        | 1   | 78 | CG305F.8-3      | Spring            | 1   |
| 19 | BG305.12.4-5 | Holder A            | 1   | 49 | GB/T9074.13   | Screw M5×25         | 6   | 79 |                 | Cord              | 2   |
| 20 | CG305F.1-3   | Holder B            | 1   | 50 | CG415D-2      | Cap, Lower          | 1   | 80 | CG305F.8-1      | Cord Holder       | 1   |
| 21 | GB/T862.1    | Washer 10           | 1   | 51 | CG330B-3      | Rubber Washer       | 2   | 81 | CG305F.8-7      | Platen            | 1   |
| 22 | CG305F.1-4   | Left Nut            | 1   | 52 | CG415D-3      | Bracket             | 1   | 82 | CG305F.8-2      | Cover             | 1   |
| 23 | GB/T91       | PIN 2×16            | 1   | 53 | CG415D.2-2B   | Handle              | 1   | 83 | BG430.2.6-1     | Bracket           | 1   |
| 24 | CG420-2B     | Blade               | 1   | 54 | CG330B-CE.3-1 | Grip Left           | 1   | 84 | GB/T9074.13     | Screw M5×30       | 2   |
| 25 | CG415-CE.1   | Pipe Comp.          | 1   | 55 | CG420-3       | Cover               | 1   | 85 | CG420.7.1-1     | Safety Guard      | 1   |
| 26 | BG-328.9.4-5 | Rubber Cover        | 6   | 56 | CG415D-1      | Cap, Upper          | 1   | 86 | GB/T9074.4      | Screw M5×16       | 4   |
| 27 | BG-328.9.4-4 | Oil-Bearing         | 6   | 57 | CG411.3-1B    | Handle              | 1   | 87 | GB/T845         | Screw ST4.2×16    | 2   |
| 28 | CG420.2-3    | Drive Shaft         | 1   | 58 | CG260B-CE.1.1 | Lever Assy          | 1   | 88 | CG420.7.1.1-1   | Guard             | 1   |
| 29 | CG415-CE.1-1 | Pipe                | 1   | 59 | GB/T846       | Screw ST2.9×13      | 1   | 89 | CG420.7.1.1-2   | Blade             | 1   |
| 30 | CG260.3      | Holder Assy         | 1   | 60 | BL750.3-9     | Button              | 1   | 90 | CG420.7.1.1     | Guard Assy        | 1   |